

# SWCE Standard for Underground Secondary Service on Overhead Primary

## To be supplied and installed by Contractor/Homeowner:

1. 200 Amp Lever Bypass Meter Socket
2. Service Disconnect
3. 6X6 Treated Post or Back Board
4. Source and Load side wire

